

# Dell EMC OpenManage Network Manager 6.2 SP3 Device Support Matrix

This document contains the list of supported device drivers and operating systems for Dell EMC Open Manage Network Manager.

## Contents

Dell EMC Networking (PowerConnect).....	1
Dell EMC Networking (Datacenter).....	5
Dell EMC SonicWall.....	7
Amigopod.....	10
Arista.....	10
Aruba.....	12
Brocade RX Series.....	13
Cisco IOS.....	15
Comware.....	39
Cumulus.....	40
Entarasys.....	40
Extreme.....	41
HP ProCurve.....	42
Juniper JUNOS.....	47
WBEM Report.....	51

## Dell EMC Networking (PowerConnect)

### Supported OS Versions

Description	About Box Display
1.0.0.x	1.0.0.x
1.0.1.x	1.0.1.x
1.0.2.x	1.0.2.x
1.0.4.x	1.0.4.x
1.1.0.x	1.1.0.x
1.2.0.x	1.2.0.x
1.2.1.x	1.2.1.x

Description	About Box Display
2.0.0.x	2.0.0.x
3.1.0.x	3.1.0.x
3.2.x	3.2.x
3.3.x	3.3.x
4.0.x	4.0.x
4.1.x	4.1.x
5.1.x	5.1.x
5.2.5.x	5.2.5.x
6.0.7.x	6.0.7.x
6.1.x	6.1.x
6.2.x	6.2.x
6.2.6.x	6.2.6.x

## Supported Device Models

Driver	OS	Model	Common Type	Entity
dellpowerconnect	Dell Networking (PCT)	3024	SWTCH	PowerConnect3024
dellpowerconnect	Dell Networking (PCT)	3048	SWTCH	PowerConnect3048
dellpowerconnect	Dell Networking (PCT)	3248	SWTCH	PowerConnect3248
dellpowerconnect	Dell Networking (PCT)	3324	SWTCH	PowerConnect33XXStackable
dellpowerconnect	Dell Networking (PCT)	3348	SWTCH	PowerConnect33XXStackable
dellpowerconnect	Dell Networking (PCT)	Dell Networking N1524	SWTCH	NetworkingSwitch
dellpowerconnect	Dell Networking (PCT)	Dell Networking N1524P	SWTCH	PoESwitch
dellpowerconnect	Dell Networking (PCT)	Dell Networking N1548	SWTCH	NetworkingSwitch
dellpowerconnect	Dell Networking (PCT)	Dell Networking N1548P	SWTCH	PoESwitch
dellpowerconnect	Dell Networking (PCT)	Dell Networking N2024	SWTCH	NetworkingSwitch
dellpowerconnect	Dell Networking (PCT)	Dell Networking N2024P	SWTCH	PoESwitch
dellpowerconnect	Dell Networking (PCT)	Dell Networking N2048	SWTCH	NetworkingSwitch
dellpowerconnect	Dell Networking (PCT)	Dell Networking N2048P	SWTCH	PoESwitch
dellpowerconnect	Dell Networking (PCT)	Dell Networking N3024	SWTCH	NetworkingSwitch

Driver	OS	Model	Common Type	Entity
dellpowerconnect	Dell Networking (PCT)	Dell Networking N3024F	SWTCH	NetworkingSwitch
dellpowerconnect	Dell Networking (PCT)	Dell Networking N3024P	SWTCH	PoESwitch
dellpowerconnect	Dell Networking (PCT)	Dell Networking N3048	SWTCH	NetworkingSwitch
dellpowerconnect	Dell Networking (PCT)	Dell Networking N3048P	SWTCH	PoESwitch
dellpowerconnect	Dell Networking (PCT)	Dell Networking N3132PX	SWTCH	NetworkingSwitch
dellpowerconnect	Dell Networking (PCT)	Dell Networking N4032/ PowerConnect 8132	SWTCH	PowerConnect8164
dellpowerconnect	Dell Networking (PCT)	Dell Networking N4032F/ PowerConnect 8132F	SWTCH	PowerConnect8164
dellpowerconnect	Dell Networking (PCT)	Dell Networking N4064/ PowerConnect 8164	SWTCH	PowerConnect8164
dellpowerconnect	Dell Networking (PCT)	Dell Networking N4064F/ PowerConnect 8164F	SWTCH	PowerConnect8164
dellpowerconnect	Dell Networking (PCT)	Dell Networking X1008	SWTCH	NetworkingSwitch
dellpowerconnect	Dell Networking (PCT)	Dell Networking X1008P	SWTCH	NetworkingSwitch
dellpowerconnect	Dell Networking (PCT)	Dell Networking X1018	SWTCH	NetworkingSwitch
dellpowerconnect	Dell Networking (PCT)	Dell Networking X1018P	SWTCH	NetworkingSwitch
dellpowerconnect	Dell Networking (PCT)	Dell Networking X1026	SWTCH	NetworkingSwitch
dellpowerconnect	Dell Networking (PCT)	Dell Networking X1026P	SWTCH	NetworkingSwitch
dellpowerconnect	Dell Networking (PCT)	Dell Networking X1052	SWTCH	NetworkingSwitch
dellpowerconnect	Dell Networking (PCT)	Dell Networking X1052P	SWTCH	NetworkingSwitch
dellpowerconnect	Dell Networking (PCT)	Dell Networking X4012	SWTCH	NetworkingSwitch
dellpowerconnect	Dell Networking (PCT)	Dell PowerEdge VRTX 10Gb	SWTCH	PowerConnect5524
dellpowerconnect	Dell Networking (PCT)	Dell PowerEdge VRTX 1Gb IOM	SWTCH	PowerConnect5524
dellpowerconnect	Dell Networking (PCT)	PowerConnect 3424	SWTCH	PowerConnect34XXStac kable
dellpowerconnect	Dell Networking (PCT)	PowerConnect 3424P	SWTCH	PowerConnect34XXPSta ckable
dellpowerconnect	Dell Networking (PCT)	PowerConnect 3448	SWTCH	PowerConnect34XXStac kable

Driver	OS	Model	Common Type	Entity
dellpowerconnect	Dell Networking (PCT)	PowerConnect 3448P	SWTCH	PowerConnect34XXPStackable
dellpowerconnect	Dell Networking (PCT)	PowerConnect 3524	SWTCH	PowerConnect35XXStackable
dellpowerconnect	Dell Networking (PCT)	PowerConnect 3524P	SWTCH	PowerConnect35XXPStackable
dellpowerconnect	Dell Networking (PCT)	PowerConnect 3548	SWTCH	PowerConnect35XXStackable
dellpowerconnect	Dell Networking (PCT)	PowerConnect 3548P	SWTCH	PowerConnect35XXPStackable
dellpowerconnect	Dell Networking (PCT)	PowerConnect 5012	SWTCH	PowerConnect5012
dellpowerconnect	Dell Networking (PCT)	PowerConnect 5212	SWTCH	PowerConnect5212
dellpowerconnect	Dell Networking (PCT)	PowerConnect 5224	SWTCH	PowerConnect5224
dellpowerconnect	Dell Networking (PCT)	PowerConnect 5316	SWTCH	PowerConnect5316
dellpowerconnect	Dell Networking (PCT)	PowerConnect 5324	SWTCH	PowerConnect5324
dellpowerconnect	Dell Networking (PCT)	PowerConnect 5424	SWTCH	PowerConnect5424
dellpowerconnect	Dell Networking (PCT)	PowerConnect 5448	SWTCH	PowerConnect5448
dellpowerconnect	Dell Networking (PCT)	PowerConnect 5524	SWTCH	PowerConnect5524
dellpowerconnect	Dell Networking (PCT)	PowerConnect 5524P	SWTCH	PoESwitch
dellpowerconnect	Dell Networking (PCT)	PowerConnect 5548	SWTCH	PowerConnect5524
dellpowerconnect	Dell Networking (PCT)	PowerConnect 5548P	SWTCH	PoESwitch
dellpowerconnect	Dell Networking (PCT)	PowerConnect 6224	SWTCH	PowerConnect62XXStackable
dellpowerconnect	Dell Networking (PCT)	PowerConnect 6224F	SWTCH	PowerConnect62XXStackable
dellpowerconnect	Dell Networking (PCT)	PowerConnect 6224P	SWTCH	PowerConnect62XXPStackable
dellpowerconnect	Dell Networking (PCT)	PowerConnect 6248	SWTCH	PowerConnect62XXStackable
dellpowerconnect	Dell Networking (PCT)	PowerConnect 6248P	SWTCH	PowerConnect62XXPStackable
dellpowerconnect	Dell Networking (PCT)	PowerConnect 7024	SWTCH	PowerConnect7024
dellpowerconnect	Dell Networking (PCT)	PowerConnect 7024F	SWTCH	PowerConnect7024F

Driver	OS	Model	Common Type	Entity
dellpowerconnect	Dell Networking (PCT)	PowerConnect 7024P	SWTCH	PowerConnect7024P
dellpowerconnect	Dell Networking (PCT)	PowerConnect 7048	SWTCH	PowerConnect7048
dellpowerconnect	Dell Networking (PCT)	PowerConnect 7048P	SWTCH	PowerConnect7048P
dellpowerconnect	Dell Networking (PCT)	PowerConnect 7048R	SWTCH	PowerConnect7048R
dellpowerconnect	Dell Networking (PCT)	PowerConnect 7048RA	SWTCH	PowerConnect7048RA
dellpowerconnect	Dell Networking (PCT)	PowerConnect 8024	SWTCH	PowerConnect8024
dellpowerconnect	Dell Networking (PCT)	PowerConnect 8024F	SWTCH	PowerConnect8024
dellpowerconnect	Dell Networking (PCT)	PowerConnect M6220	SWTCH	PowerConnect62XXStackable
dellpowerconnect	Dell Networking (PCT)	PowerConnect M6348	SWTCH	PowerConnectM6348
dellpowerconnect	Dell Networking (PCT)	PowerConnect M8024	SWTCH	PowerConnectM8024
dellpowerconnect	Dell Networking (PCT)	PowerConnect M8024-k	SWTCH	PowerConnectM8024-k

## Dell EMC Networking (Datacenter)

### Supported OS Versions

Description	About Box Display
Dell Networking OS 8.3.x	8.3.x
Dell Networking OS 8.4.x	8.4.x
E8.4..7.0(for Dell Networking C Series)	E8.4.7.0
Dell Networking OS 9.1.x	9.1.x
Dell Networking OS 9.3.x	9.3.x
Dell Networking OS 9.4.x	9.4.x
Dell Networking OS 9.5.x	9.5.x
Dell Networking OS 9.6.x	9.6.x
Dell Networking OS 9.7.x	9.7.x
Dell Networking OS 9.8.x	9.8.x
Dell Networking OS 9.9.x	9.9.x

Driver	OS	Model	Common Type	Entity
force10	Dell Networking (FTOS)	Dell Networking C7004/ C150	SWTCH	C-Series
force10	Dell Networking (FTOS)	Dell Networking C7008/ C300	SWTCH	C-Series
force10	Dell Networking (FTOS)	Dell Networking C9010	SWTCH	C9010
force10	Dell Networking (FTOS)	Dell Networking E1200	SWTCH	E-Series
force10	Dell Networking (FTOS)	Dell Networking E1200i	SWTCH	E-Series
force10	Dell Networking (FTOS)	Dell Networking E300	SWTCH	E-Series
force10	Dell Networking (FTOS)	Dell Networking E600	SWTCH	E-Series
force10	Dell Networking (FTOS)	Dell Networking E600i	SWTCH	E-Series
force10	Dell Networking (FTOS)	Dell Networking MXL10	ConvergedEthernetSwitc h	S5000
force10	Dell Networking (FTOS)	Dell Networking S2410CP	SWTCH	S-Series
force10	Dell Networking (FTOS)	Dell Networking S2410P	SWTCH	S-Series
force10	Dell Networking (FTOS)	Dell Networking S25N	SWTCH	S-Series
force10	Dell Networking (FTOS)	Dell Networking S25P-AC	SWTCH	S-Series
force10	Dell Networking (FTOS)	Dell Networking S25P-DC	SWTCH	S-Series
force10	Dell Networking (FTOS)	Dell Networking S25V	SWTCH	S-Series
force10	Dell Networking (FTOS)	Dell Networking S3048- ON	SWTCH	S-Series
force10	Dell Networking (FTOS)	Dell Networking S3124	SWTCH	S-Series
force10	Dell Networking (FTOS)	Dell Networking S3124F	SWTCH	S-Series
force10	Dell Networking (FTOS)	Dell Networking S3124P	SWTCH	S-Series
force10	Dell Networking (FTOS)	Dell Networking S3148	SWTCH	S-Series
force10	Dell Networking (FTOS)	Dell Networking S3148P	SWTCH	S-Series
force10	Dell Networking (FTOS)	Dell Networking S4048- ON	SWTCH	S-Series
force10	Dell Networking (FTOS)	Dell Networking S4048T- ON	SWTCH	S-Series
force10	Dell Networking (FTOS)	Dell Networking S4810	SWTCH	S4810
force10	Dell Networking (FTOS)	Dell Networking S4810- ON	SWTCH	S4810

Driver	OS	Model	Common Type	Entity
force10	Dell Networking (FTOS)	Dell Networking S4820T	SWTCH	S4810
force10	Dell Networking (FTOS)	Dell Networking S50	SWTCH	S-Series
force10	Dell Networking (FTOS)	Dell Networking S5000	ConvergedEthernetSwitch	S5000
force10	Dell Networking (FTOS)	Dell Networking S50E	SWTCH	S-Series
force10	Dell Networking (FTOS)	Dell Networking S50N	SWTCH	S-Series
force10	Dell Networking (FTOS)	Dell Networking S50N-AC	SWTCH	S-Series
force10	Dell Networking (FTOS)	Dell Networking S50V	SWTCH	S-Series
force10	Dell Networking (FTOS)	Dell Networking S55	SWTCH	S-Series
force10	Dell Networking (FTOS)	Dell Networking S60	SWTCH	S-Series
force10	Dell Networking (FTOS)	Dell Networking S6000	SWTCH	S4810
force10	Dell Networking (FTOS)	Dell Networking S6000-ON	SWTCH	S-Series
force10	Dell Networking (FTOS)	Dell Networking S6010	SWTCH	S-Series
force10	Dell Networking (FTOS)	Dell Networking S6100	SWTCH	S-Series
force10	Dell Networking (FTOS)	Dell Networking Z9000	SWTCH	S-Series
force10	Dell Networking (FTOS)	Dell Networking Z9000	SWTCH	S-Series
force10	Dell Networking (FTOS)	Dell Networking Z9100-ON	SWTCH	S-Series
force10	Dell Networking (FTOS)	Dell Networking Z9500	SWTCH	S-Series
force10	Dell Networking (FTOS)	Dell PowerEdge FN IOA	SWTCH	S5000
force10	Dell Networking (FTOS)	Dell PowerEdge M I/O Aggregator	ConvergedEthernetSwitch	S5000

## Dell EMC SonicWall

### Supported OS Versions

Description	About Box Display
5.8.x	5.8.x
5.9.x	5.9.x

6.1.x

6.1.x

## Supported Device Models

Driver	OS	Model	Common Type	Entity
sonicwall	SonicOS	Generic SonicWALL	Firewall	SONICWALL
sonicwall	SonicOS	Generic SonicWALL SRA	Firewall	SONICWALL
sonicwall	SonicOS	SonicWALL NSA 220	Firewall	SONICWALL
sonicwall	SonicOS	SonicWALL NSA 220 Wireless	Firewall	SONICWALL
sonicwall	SonicOS	SonicWALL NSA 240	Firewall	SONICWALL
sonicwall	SonicOS	SonicWALL NSA 2400	Firewall	SONICWALL
sonicwall	SonicOS	SonicWALL NSA 250M	Firewall	SONICWALL
sonicwall	SonicOS	SonicWALL NSA 250M Wireless	Firewall	SONICWALL
sonicwall	SonicOS	SonicWALL NSA 2600	Firewall	SONICWALL
sonicwall	SonicOS	SonicWALL NSA 3500	Firewall	SONICWALL
sonicwall	SonicOS	SonicWALL NSA 3600	Firewall	SONICWALL
sonicwall	SonicOS	SonicWALL NSA 4500	Firewall	SONICWALL
sonicwall	SonicOS	SonicWALL NSA 4600	Firewall	SONICWALL
sonicwall	SonicOS	SonicWALL NSA 5600	Firewall	SONICWALL
sonicwall	SonicOS	SonicWALL NSA 6600	Firewall	SONICWALL
sonicwall	SonicOS	SonicWALL NSA E5500	Firewall	SONICWALL
sonicwall	SonicOS	SonicWALL NSA E6500	Firewall	SONICWALL
sonicwall	SonicOS	SonicWALL NSA E7500	Firewall	SONICWALL
sonicwall	SonicOS	SonicWALL NSA E8500	Firewall	SONICWALL
sonicwall	SonicOS	SonicWALL NSA E8510	Firewall	SONICWALL
sonicwall	SonicOS	SonicWALL PRO 1260	Firewall	SONICWALL
sonicwall	SonicOS	SonicWALL PRO 2040	Firewall	SONICWALL
sonicwall	SonicOS	SonicWALL PRO 4060	Firewall	SONICWALL



Driver	OS	Model	Common Type	Entity
sonicwall	SonicOS	SonicWALL PRO 5060	Firewall	SONICWALL
sonicwall	SonicOS	SonicWALL SOHO	Firewall	SONICWALL
sonicwall	SonicOS	SonicWALL SOHO WIRELESS	Firewall	SONICWALL
sonicwall	SonicOS	SonicWALL SRA 1200	Firewall	SONICWALL
sonicwall	SonicOS	SonicWALL SRA 1600	Firewall	SONICWALL
sonicwall	SonicOS	SonicWALL SRA 4600	Firewall	SONICWALL
sonicwall	SonicOS	SonicWALL SuperMassive 10200	Firewall	SONICWALL
sonicwall	SonicOS	SonicWALL SuperMassive 10400	Firewall	SONICWALL
sonicwall	SonicOS	SonicWALL SuperMassive 10800	Firewall	SONICWALL
sonicwall	SonicOS	SonicWALL SuperMassive 9200	Firewall	SONICWALL
sonicwall	SonicOS	SonicWALL SuperMassive 9400	Firewall	SONICWALL
sonicwall	SonicOS	SonicWALL SuperMassive 9600	Firewall	SONICWALL
sonicwall	SonicOS	SonicWALL SuperMassive 9800	Firewall	SONICWALL
sonicwall	SonicOS	SonicWALL TZ 100	Firewall	SONICWALL
sonicwall	SonicOS	SonicWALL TZ 105	Firewall	SONICWALL
sonicwall	SonicOS	SonicWALL TZ 105 Wireless	Firewall	SONICWALL
sonicwall	SonicOS	SonicWALL TZ 180	Firewall	SONICWALL
sonicwall	SonicOS	SonicWALL TZ 190	Firewall	SONICWALL
sonicwall	SonicOS	SonicWALL TZ 200 Wireless	Firewall	SONICWALL
sonicwall	SonicOS	SonicWALL TZ 205	Firewall	SONICWALL
sonicwall	SonicOS	SonicWALL TZ 205 Wireless	Firewall	SONICWALL
sonicwall	SonicOS	SonicWALL TZ 210	Firewall	SONICWALL

Driver	OS	Model	Common Type	Entity
sonicwall	SonicOS	SonicWALL TZ 210 Wireless	Firewall	SONICWALL
sonicwall	SonicOS	SonicWALL TZ 215	Firewall	SONICWALL
sonicwall	SonicOS	SonicWALL TZ 215 Wireless	Firewall	SONICWALL
sonicwall	SonicOS	SonicWALL TZ 300	Firewall	SONICWALL
sonicwall	SonicOS	SonicWALL TZ 300 Wireless	Firewall	SONICWALL
sonicwall	SonicOS	SonicWALL TZ 400	Firewall	SONICWALL
sonicwall	SonicOS	SonicWALL TZ 400 Wireless	Firewall	SONICWALL
sonicwall	SonicOS	SonicWALL TZ 500	Firewall	SONICWALL
sonicwall	SonicOS	SonicWALL TZ 500 Wireless	Firewall	SONICWALL
sonicwall	SonicOS	SonicWALL TZ 600	Firewall	SONICWALL

## Amigopod

### Supported Device Models

Driver	OS	Model	Common Type	Entity
amigopod	Amigopod	PowerConnect W-ClearPass GuestConnect	SVR	DDBASE.DEVICE

## Arista

### Supported OS Versions

Description	About Box Display
4.12.x	4.12
4.15.x	4.15

# Supported Device Models

Driver	OS	Model	Common Type	Entity
arista	AristaEOS	aristaDCS7048T4S	SWTCH	DDBASE.DEVICE
arista	AristaEOS	aristaDCS7048TA	SWTCH	DDBASE.DEVICE
arista	AristaEOS	aristaDCS7050Q16	SWTCH	DDBASE.DEVICE
arista	AristaEOS	aristaDCS7050Q16SSD	SWTCH	DDBASE.DEVICE
arista	AristaEOS	aristaDCS7050S52	SWTCH	DDBASE.DEVICE
arista	AristaEOS	aristaDCS7050S52SSD	SWTCH	DDBASE.DEVICE
arista	AristaEOS	aristaDCS7050S64	SWTCH	DDBASE.DEVICE
arista	AristaEOS	aristaDCS7050S64SSD	SWTCH	DDBASE.DEVICE
arista	AristaEOS	aristaDCS7050T36	SWTCH	DDBASE.DEVICE
arista	AristaEOS	aristaDCS7050T52	SWTCH	DDBASE.DEVICE
arista	AristaEOS	aristaDCS7050T52SSD	SWTCH	DDBASE.DEVICE
arista	AristaEOS	aristaDCS7050T64	SWTCH	DDBASE.DEVICE
arista	AristaEOS	aristaDCS7050T64SSD	SWTCH	DDBASE.DEVICE
arista	AristaEOS	aristaDCS7120T4S	SWTCH	DDBASE.DEVICE
arista	AristaEOS	aristaDCS7124FX	SWTCH	DDBASE.DEVICE
arista	AristaEOS	aristaDCS7124FXCL	SWTCH	DDBASE.DEVICE
arista	AristaEOS	aristaDCS7124S	SWTCH	DDBASE.DEVICE
arista	AristaEOS	aristaDCS7124SX	SWTCH	DDBASE.DEVICE
arista	AristaEOS	aristaDCS7124SXSSD	SWTCH	DDBASE.DEVICE
arista	AristaEOS	aristaDCS7140T8S	SWTCH	DDBASE.DEVICE
arista	AristaEOS	aristaDCS7148S	SWTCH	DDBASE.DEVICE
arista	AristaEOS	aristaDCS7148SX	SWTCH	DDBASE.DEVICE
arista	AristaEOS	aristaDCS7150S24	SWTCH	DDBASE.DEVICE
arista	AristaEOS	aristaDCS7150S24CL	SWTCH	DDBASE.DEVICE
arista	AristaEOS	aristaDCS7150S24CLSSD	SWTCH	DDBASE.DEVICE

Driver	OS	Model	Common Type	Entity
arista	AristaEOS	aristaDCS7150S52CL	SWTCH	DDBASE.DEVICE
arista	AristaEOS	aristaDCS7150S52CLSSD	SWTCH	DDBASE.DEVICE
arista	AristaEOS	aristaDCS7150S64CL	SWTCH	DDBASE.DEVICE
arista	AristaEOS	aristaDCS7504	SWTCH	DDBASE.DEVICE
arista	AristaEOS	aristaDCS7508	SWTCH	DDBASE.DEVICE
arista	AristaEOS	ARISTASIM	SWTCH	DDBASE.DEVICE

## Aruba

### Supported OS Versions

Description	About Box Display
Dell Networking Aruba OS 2.5.x	Dell Networking Aruba OS 2.5.x
Dell Networking Aruba OS 3.1.x	Dell Networking Aruba OS 3.1.x
Dell Networking Aruba OS 6.0.x	Dell Networking Aruba OS 6.0.x
Dell Networking Aruba OS 6.2.x	Dell Networking Aruba OS 6.2.x
Dell Networking Aruba OS 6.3.x	Dell Networking Aruba OS 6.3.x
Dell Networking Aruba OS 6.4.x	Dell Networking Aruba OS 6.4.x

### Supported Device Models

Driver	OS	Model	Common Type	Entity
aruba	ArubaOS	Access Point	WirelessAccessPoint	ACCESS_POINT
aruba	ArubaOS	Access Point 1200	WirelessAccessPoint	ACCESS_POINT
aruba	ArubaOS	Access Point 2E	WirelessAccessPoint	ACCESS_POINT
aruba	ArubaOS	Access Point 40	WirelessAccessPoint	ACCESS_POINT
aruba	ArubaOS	Access Point 41	WirelessAccessPoint	ACCESS_POINT
aruba	ArubaOS	Access Point 50	WirelessAccessPoint	ACCESS_POINT
aruba	ArubaOS	Access Point 52	WirelessAccessPoint	ACCESS_POINT
aruba	ArubaOS	Access Point 60	WirelessAccessPoint	ACCESS_POINT
aruba	ArubaOS	Access Point 61	WirelessAccessPoint	ACCESS_POINT

Driver	OS	Model	Common Type	Entity
aruba	ArubaOS	Access Point 61a	WirelessAccessPoint	ACCESS_POINT
aruba	ArubaOS	Access Point 65	WirelessAccessPoint	ACCESS_POINT
aruba	ArubaOS	Access Point 70	WirelessAccessPoint	ACCESS_POINT
aruba	ArubaOS	Access Point 80M	WirelessAccessPoint	ACCESS_POINT
aruba	ArubaOS	Access Point 80MB	WirelessAccessPoint	ACCESS_POINT
aruba	ArubaOS	Access Point 80S	WirelessAccessPoint	ACCESS_POINT
aruba	ArubaOS	Access Point 80SB	WirelessAccessPoint	ACCESS_POINT
aruba	ArubaOS	Access Point Duo	WirelessAccessPoint	ACCESS_POINT
aruba	ArubaOS	Access Point Duo WJ	WirelessAccessPoint	ACCESS_POINT
aruba	ArubaOS	Access Point Mw1700	WirelessAccessPoint	ACCESS_POINT
aruba	ArubaOS	Access Point WG 102	WirelessAccessPoint	ACCESS_POINT
aruba	ArubaOS	Mobility Controller	SWTCH	CONTROLLER
aruba	ArubaOS	Mobility Controller 200	SWTCH	CONTROLLER
aruba	ArubaOS	Mobility Controller 2400	SWTCH	CONTROLLER
aruba	ArubaOS	Mobility Controller 2400E	SWTCH	CONTROLLER
aruba	ArubaOS	Mobility Controller 2424	SWTCH	CONTROLLER
aruba	ArubaOS	Mobility Controller 5000	SWTCH	CONTROLLER
aruba	ArubaOS	Mobility Controller 6000	SWTCH	CONTROLLER
aruba	ArubaOS	Mobility Controller 800	SWTCH	CONTROLLER
aruba	ArubaOS	Mobility Controller 800E	SWTCH	CONTROLLER
aruba	ArubaOS	Mobility Controller 804	SWTCH	CONTROLLER

## Brocade RX Series

### Supported OS Versions

Description	About Box Display
IronWare OS 2.7.x	IronWare OS 2.7.x

## Supported Device Models

Driver	OS	Model	Common Type	Entity
brocaderx	IronWare	ADX 1000 Router	SWTCH	ServerIronADX
brocaderx	IronWare	ADX 10000 Router	SWTCH	ServerIronADX
brocaderx	IronWare	ADX 4000 Router	SWTCH	ServerIronADX
brocaderx	IronWare	FCX 624	SWRT	FastIron_CX
brocaderx	IronWare	FCX 624 Advanced Router	SWRT	DDBASE.DEVICE
brocaderx	IronWare	FCX 624 Base L3 Router	SWRT	DDBASE.DEVICE
brocaderx	IronWare	FCX 624 Router	SWRT	DDBASE.DEVICE
brocaderx	IronWare	FCX 624S Advanced Router	SWRT	DDBASE.DEVICE
brocaderx	IronWare	FCX 624S Base L3 Router	SWRT	DDBASE.DEVICE
brocaderx	IronWare	FCX 624S Router	SWRT	DDBASE.DEVICE
brocaderx	IronWare	FCX 624S Switch	SWRT	FastIron_CX
brocaderx	IronWare	FCX-648 Advanced Router	SWRT	DDBASE.DEVICE
brocaderx	IronWare	FCX-648 Base L3 Router	SWRT	DDBASE.DEVICE
brocaderx	IronWare	FCX-648 Switch	SWRT	FastIron_CX
brocaderx	IronWare	FCX-648-Router	SWRT	BigIron_RX
brocaderx	IronWare	FCX-648S Advanced Router	SWRT	DDBASE.DEVICE
brocaderx	IronWare	FCX-648S Base L3 Router	SWRT	DDBASE.DEVICE
brocaderx	IronWare	FCX-648S Router	SWRT	DDBASE.DEVICE
brocaderx	IronWare	FCX-648S Stack FCX	SWRT	FastIron_CX
brocaderx	IronWare	FCX-648S Switch	SWRT	FastIron_CX
brocaderx	IronWare	MLXe _16	SWRT	MLXe_Router
brocaderx	IronWare	MLXe _16 Switch	SWRT	MLXe_Router
brocaderx	IronWare	MLXe 4	SWRT	MLXe_Router

Driver	OS	Model	Common Type	Entity
brocaderx	IronWare	MLXe 4 Switch	SWRT	MLXe_Router
brocaderx	IronWare	MLXe-8	SWRT	MLXe_Router
brocaderx	IronWare	MLXe-8 Switch	SWRT	MLXe_Router
brocaderx	IronWare	RX-16 Router	RTR	BigIron_RX
brocaderx	IronWare	RX-16 Switch	SWRT	DDBASE.DEVICE
brocaderx	IronWare	RX-4 Router	SWRT	DDBASE.DEVICE
brocaderx	IronWare	RX-4 Switch	SWRT	DDBASE.DEVICE
brocaderx	IronWare	RX-8 Router	SWRT	BigIron_RX
brocaderx	IronWare	RX-8 Switch	SWRT	DDBASE.DEVICE
brocaderx	IronWare	ServerIronGT E 1000 Router	SWRT	ServerIron_GT
brocaderx	IronWare	ServerIronGT E 1000 Switch	SWRT	ServerIron_GT
brocaderx	IronWare	Turbolron Router	SWRT	Turbolron
brocaderx	IronWare	Turbolron Switch	SWRT	Turbolron

## Cisco IOS

### Supported OS Versions

Description	About Box Display
71.x	CAT OS 71.x
72.x	CAT OS 72.x
73.x	CAT OS 73.x
74.x	CAT OS 74.x
75.x	CAT OS 75.x
76.x	CAT OS 76.x
81.x	CAT OS 81.x
82.x	CAT OS 82.x
83.x	CAT OS 83.x

Description	About Box Display
8.6.x	CAT OS 8.6.x
12.0.x	IOS 12.0.x
12.1.x	IOS 12.1.x
12.2.x	IOS 12.2.x
12.3.x	IOS 12.3.x
12.4.x	IOS 12.4.x
15.x	15.x
3.3.x	IOS XR 3.3.x
3.4.x	IOS XR 3.4.x
4.x	IOS XR 4.x
1.4.x	SX300 Firmware 1.4.x
3.1.x	3.1.x
5.0(3)N2(2)	5.0(3)N2(2)
Cisco NX-OS(tm) n7000, Software (n7000-s1-dk9)	Cisco NX-OS(tm) n7000, Software (n7000-s1-dk9)
7.0.x	7.0.x
7.1.x	7.1.x
7.2.x	7.2.x
8.0.x	8.0.x

## Supported Device Models

Driver	OS	Model	Common Type	Entity
catalystswitches	Cisco CATOS	3900	SWTCH	DDBASE.DEVICE
catalystswitches	Cisco CATOS	6006	SWTCH	DDBASE.DEVICE
catalystswitches	Cisco CATOS	6009	SWTCH	DDBASE.DEVICE
catalystswitches	Cisco CATOS	6504	SWTCH	DDBASE.DEVICE
catalystswitches	Cisco CATOS	2924xl(CatOS)	SWTCH	DDBASE.DEVICE
catalystswitches	Cisco CATOS	2948G	SWTCH	DDBASE.DEVICE
catalystswitches	Cisco CATOS	2948G-GE-TX	SWTCH	DDBASE.DEVICE



Driver	OS	Model	Common Type	Entity
catalystswitches	Cisco CATOS	2980G	SWTCH	DDBASE.DEVICE
catalystswitches	Cisco CATOS	2980G-A	SWTCH	DDBASE.DEVICE
catalystswitches	Cisco CATOS	4000NAM	SWTCH	DDBASE.DEVICE
catalystswitches	Cisco CATOS	4006(CatOS)	SWTCH	DDBASE.DEVICE
catalystswitches	Cisco CATOS	4006SW	SWTCH	DDBASE.DEVICE
catalystswitches	Cisco CATOS	4503SW	SWTCH	DDBASE.DEVICE
catalystswitches	Cisco CATOS	4506SW	SWTCH	DDBASE.DEVICE
catalystswitches	Cisco CATOS	4912GSW	SWTCH	DDBASE.DEVICE
catalystswitches	Cisco CATOS	5000SW	SWTCH	DDBASE.DEVICE
catalystswitches	Cisco CATOS	5002SW	SWTCH	DDBASE.DEVICE
catalystswitches	Cisco CATOS	5500SW	SWTCH	DDBASE.DEVICE
catalystswitches	Cisco CATOS	5505SW	SWTCH	DDBASE.DEVICE
catalystswitches	Cisco CATOS	5509SW	SWTCH	DDBASE.DEVICE
catalystswitches	Cisco CATOS	6503WSC	SWTCH	DDBASE.DEVICE
catalystswitches	Cisco CATOS	6506NEB	SWTCH	DDBASE.DEVICE
catalystswitches	Cisco CATOS	6506WSC	SWTCH	DDBASE.DEVICE
catalystswitches	Cisco CATOS	6509NEB	SWTCH	DDBASE.DEVICE
catalystswitches	Cisco CATOS	6509WSC	SWTCH	DDBASE.DEVICE
catalystswitches	Cisco CATOS	6513WSC	SWTCH	DDBASE.DEVICE
catalystswitches	Cisco CATOS	C2900SW	SWTCH	DDBASE.DEVICE
catalystswitches	Cisco CATOS	C2926SW	SWTCH	DDBASE.DEVICE
catalystswitches	Cisco CATOS	OSR7603	SWTCH	DDBASE.DEVICE
catalystswitches	Cisco CATOS	OSR7606	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	801	RTR	DDBASE.DEVICE
cisco	Cisco IOS	802	RTR	DDBASE.DEVICE
cisco	Cisco IOS	803	RTR	DDBASE.DEVICE
cisco	Cisco IOS	804	RTR	DDBASE.DEVICE
cisco	Cisco IOS	805	RTR	DDBASE.DEVICE

Driver	OS	Model	Common Type	Entity
cisco	Cisco IOS	806	RTR	DDBASE.DEVICE
cisco	Cisco IOS	811	RTR	DDBASE.DEVICE
cisco	Cisco IOS	813	RTR	DDBASE.DEVICE
cisco	Cisco IOS	819	RTR	DDBASE.DEVICE
cisco	Cisco IOS	826	RTR	DDBASE.DEVICE
cisco	Cisco IOS	827	RTR	DDBASE.DEVICE
cisco	Cisco IOS	828	RTR	DDBASE.DEVICE
cisco	Cisco IOS	831	RTR	DDBASE.DEVICE
cisco	Cisco IOS	836	RTR	DDBASE.DEVICE
cisco	Cisco IOS	837	RTR	DDBASE.DEVICE
cisco	Cisco IOS	851	RTR	DDBASE.DEVICE
cisco	Cisco IOS	857	RTR	DDBASE.DEVICE
cisco	Cisco IOS	860	RTR	DDBASE.DEVICE
cisco	Cisco IOS	861	RTR	DDBASE.DEVICE
cisco	Cisco IOS	867	RTR	DDBASE.DEVICE
cisco	Cisco IOS	871	RTR	DDBASE.DEVICE
cisco	Cisco IOS	876	RTR	DDBASE.DEVICE
cisco	Cisco IOS	877	RTR	DDBASE.DEVICE
cisco	Cisco IOS	878	RTR	DDBASE.DEVICE
cisco	Cisco IOS	881	RTR	DDBASE.DEVICE
cisco	Cisco IOS	888	RTR	DDBASE.DEVICE
cisco	Cisco IOS	891	RTR	DDBASE.DEVICE
cisco	Cisco IOS	892	RTR	DDBASE.DEVICE
cisco	Cisco IOS	1000	RTR	DDBASE.DEVICE
cisco	Cisco IOS	1003	RTR	DDBASE.DEVICE
cisco	Cisco IOS	1004	RTR	DDBASE.DEVICE
cisco	Cisco IOS	1005	RTR	DDBASE.DEVICE
cisco	Cisco IOS	1401	RTR	DDBASE.DEVICE

Driver	OS	Model	Common Type	Entity
cisco	Cisco IOS	1407	RTR	DDBASE.DEVICE
cisco	Cisco IOS	1417	RTR	DDBASE.DEVICE
cisco	Cisco IOS	1502	RTR	DDBASE.DEVICE
cisco	Cisco IOS	1503	RTR	DDBASE.DEVICE
cisco	Cisco IOS	1601	RTR	DDBASE.DEVICE
cisco	Cisco IOS	1602	RTR	DDBASE.DEVICE
cisco	Cisco IOS	1603	RTR	DDBASE.DEVICE
cisco	Cisco IOS	1604	RTR	DDBASE.DEVICE
cisco	Cisco IOS	1605	RTR	DDBASE.DEVICE
cisco	Cisco IOS	1701	RTR	DDBASE.DEVICE
cisco	Cisco IOS	1710	RTR	DDBASE.DEVICE
cisco	Cisco IOS	1711	RTR	DDBASE.DEVICE
cisco	Cisco IOS	1712	RTR	DDBASE.DEVICE
cisco	Cisco IOS	1720	RTR	DDBASE.DEVICE
cisco	Cisco IOS	1721	RTR	DDBASE.DEVICE
cisco	Cisco IOS	1750	RTR	DDBASE.DEVICE
cisco	Cisco IOS	1751	RTR	DDBASE.DEVICE
cisco	Cisco IOS	1760	RTR	DDBASE.DEVICE
cisco	Cisco IOS	1801	RTR	DDBASE.DEVICE
cisco	Cisco IOS	1802	RTR	DDBASE.DEVICE
cisco	Cisco IOS	1803	RTR	DDBASE.DEVICE
cisco	Cisco IOS	1811	RTR	DDBASE.DEVICE
cisco	Cisco IOS	1812	RTR	DDBASE.DEVICE
cisco	Cisco IOS	1841	RTR	DDBASE.DEVICE
cisco	Cisco IOS	1900	RTR	DDBASE.DEVICE
cisco	Cisco IOS	1905	RTR	DDBASE.DEVICE
cisco	Cisco IOS	1941	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2000	RTR	DDBASE.DEVICE

<b>Driver</b>	<b>OS</b>	<b>Model</b>	<b>Common Type</b>	<b>Entity</b>
cisco	Cisco IOS	2102	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2202	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2501	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2502	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2503	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2504	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2505	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2506	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2507	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2508	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2509	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2510	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2511	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2512	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2513	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2514	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2515	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2516	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2517	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2518	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2519	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2520	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2521	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2522	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2523	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2524	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2525	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2610	RTR	DDBASE.DEVICE

<b>Driver</b>	<b>OS</b>	<b>Model</b>	<b>Common Type</b>	<b>Entity</b>
cisco	Cisco IOS	2611	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2612	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2613	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2620	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2621	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2650	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2651	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2691	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2801	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2811	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2821	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2851	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2901	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2921	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2951	RTR	DDBASE.DEVICE
cisco	Cisco IOS	3560	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	3620	RTR	DDBASE.DEVICE
cisco	Cisco IOS	3640	RTR	DDBASE.DEVICE
cisco	Cisco IOS	3660	RTR	DDBASE.DEVICE
cisco	Cisco IOS	3725	RTR	DDBASE.DEVICE
cisco	Cisco IOS	3745	RTR	DDBASE.DEVICE
cisco	Cisco IOS	3825	RTR	DDBASE.DEVICE
cisco	Cisco IOS	3845	RTR	DDBASE.DEVICE
cisco	Cisco IOS	3925	RTR	DDBASE.DEVICE
cisco	Cisco IOS	3945	RTR	DDBASE.DEVICE
cisco	Cisco IOS	4000	RTR	DDBASE.DEVICE
cisco	Cisco IOS	4006	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	4200	SWTCH	DDBASE.DEVICE

<b>Driver</b>	<b>OS</b>	<b>Model</b>	<b>Common Type</b>	<b>Entity</b>
cisco	Cisco IOS	4500	RTR	DDBASE.DEVICE
cisco	Cisco IOS	4503	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	4506	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	4507	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	4510	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	4700	RTR	DDBASE.DEVICE
cisco	Cisco IOS	4948	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	6500	SWRT	DDBASE.DEVICE
cisco	Cisco IOS	6503	SWRT	DDBASE.DEVICE
cisco	Cisco IOS	6504	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	6506	SWRT	DDBASE.DEVICE
cisco	Cisco IOS	6509	SWRT	DDBASE.DEVICE
cisco	Cisco IOS	6513	SWRT	DDBASE.DEVICE
cisco	Cisco IOS	7202	RTR	DDBASE.DEVICE
cisco	Cisco IOS	7204	RTR	DDBASE.DEVICE
cisco	Cisco IOS	7206	RTR	DDBASE.DEVICE
cisco	Cisco IOS	7301	RTR	DDBASE.DEVICE
cisco	Cisco IOS	7304	RTR	DDBASE.DEVICE
cisco	Cisco IOS	7505	RTR	DDBASE.DEVICE
cisco	Cisco IOS	7507	RTR	DDBASE.DEVICE
cisco	Cisco IOS	7513	RTR	DDBASE.DEVICE
cisco	Cisco IOS	7576	RTR	DDBASE.DEVICE
cisco	Cisco IOS	7604	RTR	DDBASE.DEVICE
cisco	Cisco IOS	7609	RTR	DDBASE.DEVICE
cisco	Cisco IOS	7613	RTR	DDBASE.DEVICE
cisco	Cisco IOS	10005	RTR	DDBASE.DEVICE
cisco	Cisco IOS	10008	RTR	DDBASE.DEVICE
cisco	Cisco IOS	10012	RTR	DDBASE.DEVICE

Driver	OS	Model	Common Type	Entity
cisco	Cisco IOS	10400	RTR	DDBASE.DEVICE
cisco	Cisco IOS	10720	RTR	DDBASE.DEVICE
cisco	Cisco IOS	12004	SWRT	DDBASE.DEVICE
cisco	Cisco IOS	12006	SWRT	DDBASE.DEVICE
cisco	Cisco IOS	12008	SWRT	DDBASE.DEVICE
cisco	Cisco IOS	12010	SWRT	DDBASE.DEVICE
cisco	Cisco IOS	12012	SWRT	DDBASE.DEVICE
cisco	Cisco IOS	12016	SWRT	DDBASE.DEVICE
cisco	Cisco IOS	12404	SWRT	DDBASE.DEVICE
cisco	Cisco IOS	12406	SWRT	DDBASE.DEVICE
cisco	Cisco IOS	12410	SWRT	DDBASE.DEVICE
cisco	Cisco IOS	12416	SWRT	DDBASE.DEVICE
cisco	Cisco IOS	295012	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	295024	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	7120000	RTR	DDBASE.DEVICE
cisco	Cisco IOS	1538M	RTR	DDBASE.DEVICE
cisco	Cisco IOS	1548M	RTR	DDBASE.DEVICE
cisco	Cisco IOS	1841-C/K9	RTR	DDBASE.DEVICE
cisco	Cisco IOS	1906CK9	RTR	DDBASE.DEVICE
cisco	Cisco IOS	1921K9	RTR	DDBASE.DEVICE
cisco	Cisco IOS	1941W	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2400-24TS A	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	2400-24TS D	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	2420IAD	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2504 K9	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2520-16S-8PC	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2520-24TC	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2610M	RTR	DDBASE.DEVICE

Driver	OS	Model	Common Type	Entity
cisco	Cisco IOS	2610XM	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2611M	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2611XM	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2620XM	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2621XM	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2650XM	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2651XM	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2801-C/K9	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2811-C/K9	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2821-C/K9	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2851-C/K9	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2908xl	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	2911/K9	RTR	DDBASE.DEVICE
cisco	Cisco IOS	2912fxl	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	2912LREXL	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	2912mxl	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	2916xl	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	2924cxl	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	2924fcx1	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	2924fx1	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	2924LREXL	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	2924mxl	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	2924XL	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	2948GL3	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	2948gL3	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	295012G	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	295024C	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	295024G	SWTCH	DDBASE.DEVICE



Driver	OS	Model	Common Type	Entity
cisco	Cisco IOS	295024GDC	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	295024LREG	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	295024LRESt	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	295024S	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	295024SX	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	295048G	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	295048SX	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	295048T	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	29508LRESt	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	2950T	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	2955C12	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	2955S12	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	2955T12	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	2960-24LC-S	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	2960-24LT-L	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	2960-24PC-L	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	2960-24PC-S	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	2960-24-S	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	2960-24TC	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	2960-24TC-S	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	2960-24TT	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	2960-48PST-L	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	2960-48PST-S	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	2960-48TC	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	2960-48TC-S	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	2960-48TT	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	2960-48TT-S	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	2960-8TC	SWTCH	DDBASE.DEVICE

Driver	OS	Model	Common Type	Entity
cisco	Cisco IOS	2960-8TC-S	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	2960G-24TC	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	2960G-8TC	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	2960PD-8TT-L	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	2960-S	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	2960S-24PD-L	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	2960S-24PS-L	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	2960S-48FPD-L	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	2960S-48FPS-L	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	2960S-48LPD-L	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	2960S-48LPS-L	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	2970G-24TS-E	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	3400-24TS A	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	3400-24TS-D	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	3400E-24TS M	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	3400EG-12CS M	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	3400EG-2CS A	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	3400G-12CS A	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	3400G-12CS D	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	3400G-2CS A	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	3508G-XL	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	3512XL	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	3524tXLEn	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	3524XL	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	3548XL	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	3550-12G	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	3550-12T	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	3550-24	SWTCH	DDBASE.DEVICE

Driver	OS	Model	Common Type	Entity
cisco	Cisco IOS	3550-24-DC	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	3550-24Mmf	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	3550-48	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	3550PWR-24	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	356024PS	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	356048PS	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	3560-8PC	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	3560E-24PD	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	3560E-24TD	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	3560E-48PD	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	3560E-48TD	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	3560G24PS	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	3560G24TS	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	3560G48PS	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	3560G48TS	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	3560X-24	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	3560X-24P	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	3560X-48	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	3560X-48P	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	3600X-24TS	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	3650E-48TS	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	3661Ac	RTR	DDBASE.DEVICE
cisco	Cisco IOS	3661Dc	RTR	DDBASE.DEVICE
cisco	Cisco IOS	3662Ac	RTR	DDBASE.DEVICE
cisco	Cisco IOS	3662AcCo	RTR	DDBASE.DEVICE
cisco	Cisco IOS	3662Dc	RTR	DDBASE.DEVICE
cisco	Cisco IOS	3662DcCo	RTR	DDBASE.DEVICE
cisco	Cisco IOS	3750_24	SWTCH	DDBASE.DEVICE

Driver	OS	Model	Common Type	Entity
cisco	Cisco IOS	3750_24T	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	3750_24TS	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	3750_48	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	375024ME	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	3750E-24PD	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	3750E-24TD	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	3750E-48PD	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	3750E-48TD	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	3750G16TD	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	3750Ge12Sfp	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	3750X-24	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	3750X-24P	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	3750X-48	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	3750X-48P	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	37xxStack	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	3800X-24FSM	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	3825-C/K9	RTR	DDBASE.DEVICE
cisco	Cisco IOS	3825-CNV/K9	RTR	DDBASE.DEVICE
cisco	Cisco IOS	3845-C/K9	RTR	DDBASE.DEVICE
cisco	Cisco IOS	3845-CNV/K9	RTR	DDBASE.DEVICE
cisco	Cisco IOS	3850-48P-S	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	3925-E	RTR	DDBASE.DEVICE
cisco	Cisco IOS	4000RSC	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	4840GL3	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	4908GL3	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	4924-10GE	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	494810GE	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	4kGateway	SWTCH	DDBASE.DEVICE

Driver	OS	Model	Common Type	Entity
cisco	Cisco IOS	5300AS	RTR	DDBASE.DEVICE
cisco	Cisco IOS	5kRsfc	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	6006IOS	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	6009IOS	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	6500-VSS-1440	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	6506(CatOS)	SWRT	DDBASE.DEVICE
cisco	Cisco IOS	6509(CatOS)	SWRT	DDBASE.DEVICE
cisco	Cisco IOS	6509-SP	SWRT	DDBASE.DEVICE
cisco	Cisco IOS	6524 GS-8S	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	6524 GT-8S	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	6K MSFC 2A Module	BLDSVR	DDBASE.DEVICE
cisco	Cisco IOS	6kGateway	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	7120Ae3	RTR	DDBASE.DEVICE
cisco	Cisco IOS	7120At3	RTR	DDBASE.DEVICE
cisco	Cisco IOS	7120Quadt1	RTR	DDBASE.DEVICE
cisco	Cisco IOS	7120Smi3	RTR	DDBASE.DEVICE
cisco	Cisco IOS	7120T3	RTR	DDBASE.DEVICE
cisco	Cisco IOS	7140Dualae3	RTR	DDBASE.DEVICE
cisco	Cisco IOS	7140Dualat3	RTR	DDBASE.DEVICE
cisco	Cisco IOS	7140Duale3	RTR	DDBASE.DEVICE
cisco	Cisco IOS	7140Dualfe	RTR	DDBASE.DEVICE
cisco	Cisco IOS	7140Dualmm3	RTR	DDBASE.DEVICE
cisco	Cisco IOS	7140Dualt3	RTR	DDBASE.DEVICE
cisco	Cisco IOS	7140Octt1	RTR	DDBASE.DEVICE
cisco	Cisco IOS	7150Dualfe	RTR	DDBASE.DEVICE
cisco	Cisco IOS	7150Dualt3	RTR	DDBASE.DEVICE
cisco	Cisco IOS	7150Octt1	RTR	DDBASE.DEVICE
cisco	Cisco IOS	7204VXR	RTR	DDBASE.DEVICE

Driver	OS	Model	Common Type	Entity
cisco	Cisco IOS	7206VXR	RTR	DDBASE.DEVICE
cisco	Cisco IOS	7401ASR	RTR	DDBASE.DEVICE
cisco	Cisco IOS	7401VXR	RTR	DDBASE.DEVICE
cisco	Cisco IOS	7507mx	RTR	DDBASE.DEVICE
cisco	Cisco IOS	7507z	RTR	DDBASE.DEVICE
cisco	Cisco IOS	7513mx	RTR	DDBASE.DEVICE
cisco	Cisco IOS	7513z	RTR	DDBASE.DEVICE
cisco	Cisco IOS	7603(WS-C6503)	SWRT	DDBASE.DEVICE
cisco	Cisco IOS	7603-IOS	RTR	DDBASE.DEVICE
cisco	Cisco IOS	7603-S	RTR	DDBASE.DEVICE
cisco	Cisco IOS	7604(WS-C6504-E)	SWRT	DDBASE.DEVICE
cisco	Cisco IOS	7606(WS-C6506)	SWRT	DDBASE.DEVICE
cisco	Cisco IOS	7606(WS-C6509-NEB)	SWRT	DDBASE.DEVICE
cisco	Cisco IOS	7606-IOS	RTR	DDBASE.DEVICE
cisco	Cisco IOS	7606-S	RTR	DDBASE.DEVICE
cisco	Cisco IOS	7609(C6509SP)	SWRT	DDBASE.DEVICE
cisco	Cisco IOS	7609(WS-C6509)	SWRT	DDBASE.DEVICE
cisco	Cisco IOS	7609(WS-C6509-NEB-A)	SWRT	DDBASE.DEVICE
cisco	Cisco IOS	7609-S	RTR	DDBASE.DEVICE
cisco	Cisco IOS	7609-S(866)	RTR	DDBASE.DEVICE
cisco	Cisco IOS	7613(C6513)	SWRT	DDBASE.DEVICE
cisco	Cisco IOS	7613(WS-C6503)	SWRT	DDBASE.DEVICE
cisco	Cisco IOS	7613(WS-C6513)	SWRT	DDBASE.DEVICE
cisco	Cisco IOS	826-4U	RTR	DDBASE.DEVICE
cisco	Cisco IOS	827_4V	RTR	DDBASE.DEVICE
cisco	Cisco IOS	827H	RTR	DDBASE.DEVICE
cisco	Cisco IOS	8510CSR	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	8510MSR	SWTCH	DDBASE.DEVICE

Driver	OS	Model	Common Type	Entity
cisco	Cisco IOS	8515CSR	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	8515MSR	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	8540CSR	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	8540MSR	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	886VA	RTR	DDBASE.DEVICE
cisco	Cisco IOS	886VAM	RTR	DDBASE.DEVICE
cisco	Cisco IOS	887VA	RTR	DDBASE.DEVICE
cisco	Cisco IOS	887VAM	RTR	DDBASE.DEVICE
cisco	Cisco IOS	887VA-SEC-K9	RTR	DDBASE.DEVICE
cisco	Cisco IOS	890Ap	RTR	DDBASE.DEVICE
cisco	Cisco IOS	A901-4C-F-D	RTR	DDBASE.DEVICE
cisco	Cisco IOS	A901-4C-FT-D	RTR	DDBASE.DEVICE
cisco	Cisco IOS	A903	RTR	DDBASE.DEVICE
cisco	Cisco IOS	AON Module	BLDSVR	DDBASE.DEVICE
cisco	Cisco IOS	ASR 1001	RTR	DDBASE.DEVICE
cisco	Cisco IOS	ASR 1002	RTR	DDBASE.DEVICE
cisco	Cisco IOS	ASR 1002 X	RTR	DDBASE.DEVICE
cisco	Cisco IOS	ASR 1002-F	RTR	DDBASE.DEVICE
cisco	Cisco IOS	ASR 1004	RTR	DDBASE.DEVICE
cisco	Cisco IOS	ASR 1006	RTR	DDBASE.DEVICE
cisco	Cisco IOS	ASR 1013	RTR	DDBASE.DEVICE
cisco	Cisco IOS	ASR 920 12 CZA	RTR	DDBASE.DEVICE
cisco	Cisco IOS	ASR 920 24 SZIM	RTR	DDBASE.DEVICE
cisco	Cisco IOS	C29408TF	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	C29408TT	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	C2970-24	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	C4510R	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	cat4500X32	SWTCH	DDBASE.DEVICE

Driver	OS	Model	Common Type	Entity
cisco	Cisco IOS	Cat6000	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	CBS-3100	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	CBS-3110	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	CBS-3120	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	CBS-3130	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	CGR-2010/K9	RTR	DDBASE.DEVICE
cisco	Cisco IOS	CSR1000V	RTR	DDBASE.DEVICE
cisco	Cisco IOS	Express50012TC	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	Express50024LC	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	Express50024PC	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	Express50024TT	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	Firewall Module	BLDSVR	DDBASE.DEVICE
cisco	Cisco IOS	IAD2430-24FXS	RTR	DDBASE.DEVICE
cisco	Cisco IOS	IAD2431-16FXS	RTR	DDBASE.DEVICE
cisco	Cisco IOS	IAD2431-1T1E1	RTR	DDBASE.DEVICE
cisco	Cisco IOS	IAD2431-8FXS	RTR	DDBASE.DEVICE
cisco	Cisco IOS	IAD2432-24FXS	RTR	DDBASE.DEVICE
cisco	Cisco IOS	IAD2435-8FXS	RTR	DDBASE.DEVICE
cisco	Cisco IOS	IE-2000-16PTC-G-L	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	IE-30004-TC	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	IE-30008-TC	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	IE-3010-16S-8PC	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	IE-3010-24TC	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	LS1010_DEVICE	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	LS1015_DEVICE	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	MSFC	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	MWR 2941-DC	RTR	DDBASE.DEVICE
cisco	Cisco IOS	MWR 2941-DC-A	RTR	DDBASE.DEVICE



Driver	OS	Model	Common Type	Entity
cisco	Cisco IOS	MWR1941DC	RTR	DDBASE.DEVICE
cisco	Cisco IOS	OS-CIGESM-18TT-EBU	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	Pro4500	RTR	DDBASE.DEVICE
cisco	Cisco IOS	Pro4700	RTR	DDBASE.DEVICE
cisco	Cisco IOS	RSM	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	SM-ES3G-16P	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	SSL Module	BLDSVR	DDBASE.DEVICE
cisco	Cisco IOS	Sup720 Module	BLDSVR	DDBASE.DEVICE
cisco	Cisco IOS	WS-C2960G-48TC-L	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	WS-C3560V2-24PS	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	WS-C3560V2-24TS	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	WS-C3560V2-24TS-SD	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	WS-C3560V2-48PS	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	WS-C3560V2-48TS	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	WS-C4503-E	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	WS-C4506-E	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	WS-C4507R-E	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	WS-C4510R-E	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	WS-C4900M	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	WS-C4948E-10GE	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	WS-C6504-E	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	WS-C6509-NEB-A	SWRT	DDBASE.DEVICE
cisco	Cisco IOS	WS-C6509-VE	SWRT	DDBASE.DEVICE
cisco	Cisco IOS	WS-C6509-VE(CatOS)	SWRT	DDBASE.DEVICE
cisco	Cisco IOS	WS-CBS-3020-HPQ	SWTCH	DDBASE.DEVICE
cisco	Cisco IOS	WS-X6302-MSM	SWTCH	DDBASE.DEVICE
ciscoslb	Cisco LAN Switches Small Business	SF 200-24	EthernetSwitch	Cisco3XX

<b>Driver</b>	<b>OS</b>	<b>Model</b>	<b>Common Type</b>	<b>Entity</b>
cicolssb	Cisco LAN Switches Small Business	SF 200-24FP	EthernetSwitch	Cisco3XX
cicolssb	Cisco LAN Switches Small Business	SF 200-24P	EthernetSwitch	Cisco3XX
cicolssb	Cisco LAN Switches Small Business	SF 200-48	EthernetSwitch	Cisco3XX
cicolssb	Cisco LAN Switches Small Business	SF 200-48P	EthernetSwitch	Cisco3XX
cicolssb	Cisco LAN Switches Small Business	SF 300-08	EthernetSwitch	Cisco3XX
cicolssb	Cisco LAN Switches Small Business	SF 300-10	EthernetSwitch	Cisco3XX
cicolssb	Cisco LAN Switches Small Business	SF 300-10MP	EthernetSwitch	Cisco3XX
cicolssb	Cisco LAN Switches Small Business	SF 300-10P	EthernetSwitch	Cisco3XX
cicolssb	Cisco LAN Switches Small Business	SF 300-20	EthernetSwitch	Cisco3XX
cicolssb	Cisco LAN Switches Small Business	SF 300-24	EthernetSwitch	Cisco3XX
cicolssb	Cisco LAN Switches Small Business	SF 300-24P	EthernetSwitch	Cisco3XX
cicolssb	Cisco LAN Switches Small Business	SF 300-28	EthernetSwitch	Cisco3XX
cicolssb	Cisco LAN Switches Small Business	SF 300-28P	EthernetSwitch	Cisco3XX
cicolssb	Cisco LAN Switches Small Business	SF 300-48	EthernetSwitch	Cisco3XX
cicolssb	Cisco LAN Switches Small Business	SF 300-48P	EthernetSwitch	Cisco3XX
cicolssb	Cisco LAN Switches Small Business	SF 300-52	EthernetSwitch	Cisco3XX
cicolssb	Cisco LAN Switches Small Business	SF 302-08	EthernetSwitch	Cisco3XX
cicolssb	Cisco LAN Switches Small Business	SF 302-08MP	EthernetSwitch	Cisco3XX
cicolssb	Cisco LAN Switches Small Business	SF 302-08P	EthernetSwitch	Cisco3XX

Driver	OS	Model	Common Type	Entity
ciscolssb	Cisco LAN Switches Small Business	SF 500-24	EthernetSwitch	Cisco3XX
ciscolssb	Cisco LAN Switches Small Business	SF 500-24P	EthernetSwitch	Cisco3XX
ciscolssb	Cisco LAN Switches Small Business	SF 500-48	EthernetSwitch	Cisco3XX
ciscolssb	Cisco LAN Switches Small Business	SF 500-48P	EthernetSwitch	Cisco3XX
ciscolssb	Cisco LAN Switches Small Business	SG 500-28	EthernetSwitch	Cisco3XX
ciscolssb	Cisco LAN Switches Small Business	SG 500-28P	EthernetSwitch	Cisco3XX
ciscolssb	Cisco LAN Switches Small Business	SG 500-52	EthernetSwitch	Cisco3XX
ciscolssb	Cisco LAN Switches Small Business	SG 500-52P	EthernetSwitch	Cisco3XX
ciscolssb	Cisco LAN Switches Small Business	SG 500X-24	EthernetSwitch	Cisco3XX
ciscolssb	Cisco LAN Switches Small Business	SG 500X-24P	EthernetSwitch	Cisco3XX
ciscolssb	Cisco LAN Switches Small Business	SG 500X-48	EthernetSwitch	Cisco3XX
ciscolssb	Cisco LAN Switches Small Business	SG 500X-48P	EthernetSwitch	Cisco3XX
ciscomds	N/A	MDS 9120	FibreChannelSwitch	MDS
ciscomds	N/A	MDS 9140	FibreChannelSwitch	MDS
ciscomds	N/A	MDS 9216	FibreChannelSwitch	MDS
ciscomds	N/A	MDS 9216A	FibreChannelSwitch	MDS
ciscomds	N/A	MDS 9506	FibreChannelSwitch	MDS
ciscomds	N/A	MDS 9509	FibreChannelSwitch	MDS
cisconx	N/A	1010	SWTCH	NEXUS_SWITCH
cisconx	N/A	2224	SWTCH	NEXUS_SWITCH
cisconx	N/A	2232	SWTCH	NEXUS_SWITCH
cisconx	N/A	2248	SWTCH	NEXUS_SWITCH

Driver	OS	Model	Common Type	Entity
cisconx	N/A	3016	SWTCH	NEXUS_SWITCH
cisconx	N/A	3048	SWTCH	NEXUS_SWITCH
cisconx	N/A	3064	SWTCH	NEXUS_SWITCH
cisconx	N/A	3548	SWTCH	NEXUS_SWITCH
cisconx	N/A	5010	SWTCH	NEXUS_SWITCH
cisconx	N/A	5020	SWTCH	NEXUS_SWITCH
cisconx	N/A	5548	SWTCH	NEXUS_SWITCH
cisconx	N/A	5596	SWTCH	NEXUS_SWITCH
cisconx	N/A	7004	SWTCH	NEXUS_SWITCH
cisconx	N/A	7009	SWTCH	NEXUS_SWITCH
cisconx	N/A	7010	SWTCH	NEXUS_SWITCH
cisconx	N/A	7018	SWTCH	NEXUS_SWITCH
cisconx	N/A	7710	SWTCH	NEXUS_SWITCH
cisconx	N/A	7718	SWTCH	NEXUS_SWITCH
cisconx	N/A	1000V	SWTCH	NEXUS_SWITCH
cisconx	N/A	2232T-10	SWTCH	NEXUS_SWITCH
cisconx	N/A	2232TME-10	SWTCH	NEXUS_SWITCH
cisconx	N/A	2248G	SWTCH	NEXUS_SWITCH
cisconx	N/A	3064P	SWTCH	NEXUS_SWITCH
cisconx	N/A	3064P-10	SWTCH	NEXUS_SWITCH
cisconx	N/A	3064T-10	SWTCH	NEXUS_SWITCH
cisconx	N/A	5020A	SWTCH	NEXUS_SWITCH
cisconx	N/A	5548U	SWTCH	NEXUS_SWITCH
cisconx	N/A	5596T	SWTCH	NEXUS_SWITCH
ciscopix	Cisco PIX/ASA	Cisco ASA 5505	FirewallVPNAppliance	ASA
ciscopix	Cisco PIX/ASA	Cisco ASA 5510	FirewallVPNAppliance	ASA
ciscopix	Cisco PIX/ASA	Cisco ASA 5510sc	FirewallVPNAppliance	ASA
ciscopix	Cisco PIX/ASA	Cisco ASA 5510sy	FirewallVPNAppliance	ASA

Driver	OS	Model	Common Type	Entity
ciscopix	Cisco PIX/ASA	Cisco ASA 5520	FirewallVPNAppliance	ASA
ciscopix	Cisco PIX/ASA	Cisco ASA 5520sc	FirewallVPNAppliance	ASA
ciscopix	Cisco PIX/ASA	Cisco ASA 5520sy	FirewallVPNAppliance	ASA
ciscopix	Cisco PIX/ASA	Cisco ASA 5540	FirewallVPNAppliance	ASA
ciscopix	Cisco PIX/ASA	Cisco ASA 5540sc	FirewallVPNAppliance	ASA
ciscopix	Cisco PIX/ASA	Cisco ASA 5540sy	FirewallVPNAppliance	ASA
ciscopix	Cisco PIX/ASA	Cisco ASA 5550	FirewallVPNAppliance	ASA
ciscopix	Cisco PIX/ASA	Cisco ASA 5550sc	FirewallVPNAppliance	ASA
ciscopix	Cisco PIX/ASA	Cisco ASA 5550sy	FirewallVPNAppliance	ASA
ciscopix	Cisco PIX/ASA	Cisco ASA 5580	FirewallVPNAppliance	ASA
ciscopix	Cisco PIX/ASA	Cisco ASA 5580sc	FirewallVPNAppliance	ASA
ciscopix	Cisco PIX/ASA	Cisco ASA 5580sy	FirewallVPNAppliance	ASA
ciscopix	Cisco PIX/ASA	Cisco ASA 5585 SSP-20	FirewallVPNAppliance	ASA
ciscopix	Cisco PIX/ASA	Cisco ASA 5585-X SSP-10	FirewallVPNAppliance	ASA
ciscopix	Cisco PIX/ASA	Cisco ASA 5585-X SSP-60	FirewallVPNAppliance	ASA
ciscopix	Cisco PIX/ASA	Cisco PIX Firewall	FirewallVPNAppliance	PIX
ciscopix	Cisco PIX/ASA	Cisco PIX Firewall 501	FirewallVPNAppliance	PIX
ciscopix	Cisco PIX/ASA	Cisco PIX Firewall 506	FirewallVPNAppliance	PIX
ciscopix	Cisco PIX/ASA	Cisco PIX Firewall 506E	FirewallVPNAppliance	PIX
ciscopix	Cisco PIX/ASA	Cisco PIX Firewall 515	FirewallVPNAppliance	PIX
ciscopix	Cisco PIX/ASA	Cisco PIX Firewall 515E	FirewallVPNAppliance	PIX
ciscopix	Cisco PIX/ASA	Cisco PIX Firewall 515Esc	FirewallVPNAppliance	PIX
ciscopix	Cisco PIX/ASA	Cisco PIX Firewall 515Esy	FirewallVPNAppliance	PIX
ciscopix	Cisco PIX/ASA	Cisco PIX Firewall 515sc	FirewallVPNAppliance	PIX
ciscopix	Cisco PIX/ASA	Cisco PIX Firewall 515sy	FirewallVPNAppliance	PIX
ciscopix	Cisco PIX/ASA	Cisco PIX Firewall 520	FirewallVPNAppliance	PIX
ciscopix	Cisco PIX/ASA	Cisco PIX Firewall 525	FirewallVPNAppliance	PIX

Driver	OS	Model	Common Type	Entity
ciscopix	Cisco PIX/ASA	Cisco PIX Firewall 525sc	FirewallVPNAppliance	PIX
ciscopix	Cisco PIX/ASA	Cisco PIX Firewall 525sy	FirewallVPNAppliance	PIX
ciscopix	Cisco PIX/ASA	Cisco PIX Firewall 535	FirewallVPNAppliance	PIX
ciscopix	Cisco PIX/ASA	Cisco PIX Firewall 535sc	FirewallVPNAppliance	PIX
ciscopix	Cisco PIX/ASA	Cisco PIX Firewall 535sy	FirewallVPNAppliance	PIX
ciscoxr	Cisco IOS-XR	12004(XR)	RTR	DEVICE.DDBASE
ciscoxr	Cisco IOS-XR	12006(XR)	RTR	DEVICE.DDBASE
ciscoxr	Cisco IOS-XR	12008(XR)	RTR	DEVICE.DDBASE
ciscoxr	Cisco IOS-XR	12010(XR)	RTR	DEVICE.DDBASE
ciscoxr	Cisco IOS-XR	12012(XR)	RTR	DEVICE.DDBASE
ciscoxr	Cisco IOS-XR	12016(XR)	RTR	DEVICE.DDBASE
ciscoxr	Cisco IOS-XR	12404(XR)	RTR	DEVICE.DDBASE
ciscoxr	Cisco IOS-XR	12406(XR)	RTR	DEVICE.DDBASE
ciscoxr	Cisco IOS-XR	12410(XR)	RTR	DEVICE.DDBASE
ciscoxr	Cisco IOS-XR	12416(XR)	RTR	DEVICE.DDBASE
ciscoxr	Cisco IOS-XR	12810(XR)	RTR	DEVICE.DDBASE
ciscoxr	Cisco IOS-XR	12816(XR)	RTR	DEVICE.DDBASE
ciscoxr	Cisco IOS-XR	ASR9001	RTR	DEVICE.DDBASE
ciscoxr	Cisco IOS-XR	ASR9006	RTR	DEVICE.DDBASE
ciscoxr	Cisco IOS-XR	ASR9010DC	RTR	DEVICE.DDBASE
ciscoxr	Cisco IOS-XR	CRS1-16Slot	RTR	DEVICE.DDBASE
ciscoxr	Cisco IOS-XR	CRS1-4Slot	RTR	DEVICE.DDBASE
ciscoxr	Cisco IOS-XR	CRS1-8Linecard	RTR	DEVICE.DDBASE
ciscoxr	Cisco IOS-XR	CRS1-8Slot	RTR	DEVICE.DDBASE
ciscoxr	Cisco IOS-XR	CRS1-Fabric	RTR	DEVICE.DDBASE

## Supported Device Models

Driver	OS	Model	Common Type	Entity
DD3com	Comware	A7510	RTR	DDBASE.DEVICE
DD3com	Comware	H3C S3100-EI	RTR	DDBASE.DEVICE
DD3com	Comware	JD377A	RTR	DDBASE.DEVICE
DD3com	Comware	MSR 50-40	RTR	DDBASE.DEVICE
DD3com	Comware	MSR20-11	RTR	DDBASE.DEVICE
DD3com	Comware	MSR20-12	RTR	DDBASE.DEVICE
DD3com	Comware	MSR20-13	RTR	DDBASE.DEVICE
DD3com	Comware	MSR20-15	RTR	DDBASE.DEVICE
DD3com	Comware	MSR20-20	RTR	DDBASE.DEVICE
DD3com	Comware	MSR20-21	RTR	DDBASE.DEVICE
DD3com	Comware	MSR20-40	RTR	DDBASE.DEVICE
DD3com	Comware	MSR30-10	RTR	DDBASE.DEVICE
DD3com	Comware	MSR30-11	RTR	DDBASE.DEVICE
DD3com	Comware	MSR30-16	RTR	DDBASE.DEVICE
DD3com	Comware	MSR30-20	RTR	DDBASE.DEVICE
DD3com	Comware	MSR30-40	RTR	DDBASE.DEVICE
DD3com	Comware	MSR30-60	RTR	DDBASE.DEVICE
DD3com	Comware	MSR50-60	RTR	DDBASE.DEVICE
DD3com	Comware	MSR50-series	RTR	DDBASE.DEVICE

# Cumulus

## Supported Device Models

Driver	OS	Model	Common Type	Entity
ddcumulus	Cumulus	cumulus	SWTCH	DDBASE.DEVICE

# Enterasys

## Supported Device Models

Driver	OS	Model	Common Type	Entity
enterasys	EOS	1H582-51	SWTCH	ENTERASYS_SWITCH
enterasys	EOS	A2H124-24	SWTCH	ENTERASYS_SWITCH
enterasys	EOS	A2H124-48P	SWTCH	ENTERASYS_SWITCH
enterasys	EOS	A4H124-24P	SWTCH	ENTERASYS_SWITCH
enterasys	EOS	A4H124-48P	SWTCH	ENTERASYS_SWITCH
enterasys	EOS	A4H254-8F8T	SWTCH	ENTERASYS_SWITCH
enterasys	EOS	B2H124-48P	SWTCH	ENTERASYS_SWITCH
enterasys	EOS	B3G124-24	SWTCH	ENTERASYS_SWITCH
enterasys	EOS	B3G124-48	SWTCH	ENTERASYS_SWITCH
enterasys	EOS	B5G124-24	SWTCH	ENTERASYS_SWITCH
enterasys	EOS	B5G124-48	SWTCH	ENTERASYS_SWITCH
enterasys	EOS	B5K125-24	SWTCH	ENTERASYS_SWITCH
enterasys	EOS	B5K125-48	SWTCH	ENTERASYS_SWITCH
enterasys	EOS	C5K175-24	SWTCH	ENTERASYS_SWITCH
enterasys	EOS	D2G124-12P	SWTCH	ENTERASYS_SWITCH
enterasys	EOS	G3G124-24P	SWTCH	ENTERASYS_SWITCH
enterasys	EOS	G3G170-24	SWTCH	ENTERASYS_SWITCH
enterasys	EOS	S4 Management Entity	SWTCH	ENTERASYS_SWITCH



Driver	OS	Model	Common Type	Entity
enterasys	EOS	Virtual Switch Bonded S4 Management Entity	SWTCH	ENTERASYS_SWITCH
enterasys	EOS	X4 Management Entity	SWTCH	ENTERASYS_SWITCH

## Extreme

### Supported Device Models

Driver	OS	Model	Common Type	Entity
extreme	N/A	Alpine 3802	SWTCH	ExtremeSwitch
extreme	N/A	Alpine 3804	SWTCH	ExtremeSwitch
extreme	N/A	Alpine 3808	SWTCH	ExtremeSwitch
extreme	N/A	Black Diamond 10808	SWTCH	ExtremeSwitch
extreme	N/A	Black Diamond 12804	SWTCH	ExtremeSwitch
extreme	N/A	Black Diamond 6800	SWTCH	ExtremeSwitch
extreme	N/A	Black Diamond 6804	SWTCH	ExtremeSwitch
extreme	N/A	Black Diamond 6808	SWTCH	ExtremeSwitch
extreme	N/A	Black Diamond 6816	SWTCH	ExtremeSwitch
extreme	N/A	Black Diamond 8800	SWTCH	ExtremeSwitch
extreme	N/A	Black Diamond 8810	SWTCH	ExtremeSwitch
extreme	N/A	Summit 1	SWTCH	ExtremeSwitch
extreme	N/A	Summit 1iSX	SWTCH	ExtremeSwitch
extreme	N/A	Summit 1iT X	SWTCH	ExtremeSwitch
extreme	N/A	Summit 2	SWTCH	ExtremeSwitch
extreme	N/A	Summit 200-24	SWTCH	ExtremeSwitch
extreme	N/A	Summit 200-24fx	SWTCH	ExtremeSwitch
extreme	N/A	Summit 200-48	SWTCH	ExtremeSwitch
extreme	N/A	Summit 24	SWTCH	ExtremeSwitch
extreme	N/A	Summit 24e2SX	SWTCH	ExtremeSwitch
extreme	N/A	Summit 24e2TX	SWTCH	ExtremeSwitch
extreme	N/A	Summit 24e3	SWTCH	ExtremeSwitch
extreme	N/A	Summit 3	SWTCH	ExtremeSwitch
extreme	N/A	Summit 300-24	SWTCH	ExtremeSwitch
extreme	N/A	Summit 300-48	SWTCH	ExtremeSwitch
extreme	N/A	Summit 4	SWTCH	ExtremeSwitch

Driver	OS	Model	Common Type	Entity
extreme	N/A	Summit 400-24p	SWTCH	ExtremeSwitch
extreme	N/A	Summit 400-24ta	SWTCH	ExtremeSwitch
extreme	N/A	Summit 400-24tb	SWTCH	ExtremeSwitch
extreme	N/A	Summit 400-24x	SWTCH	ExtremeSwitch
extreme	N/A	Summit 400-48t	SWTCH	ExtremeSwitch
extreme	N/A	Summit 450a-24t	SWTCH	ExtremeSwitch
extreme	N/A	Summit 48	SWTCH	ExtremeSwitch
extreme	N/A	Summit 48i	SWTCH	ExtremeSwitch
extreme	N/A	Summit 48si	SWTCH	ExtremeSwitch
extreme	N/A	Summit 4fx	SWTCH	ExtremeSwitch
extreme	N/A	Summit 5i	SWTCH	ExtremeSwitch
extreme	N/A	Summit 5iLX	SWTCH	ExtremeSwitch
extreme	N/A	Summit 5iTX	SWTCH	ExtremeSwitch
extreme	N/A	Summit 7iSX	SWTCH	ExtremeSwitch
extreme	N/A	Summit 7iTX	SWTCH	ExtremeSwitch
extreme	N/A	Summit Px1	SWTCH	ExtremeSwitch
extreme	N/A	Summit WM 100	SWTCH	ExtremeSwitch
extreme	N/A	Summit WM 1000	SWTCH	ExtremeSwitch
extreme	N/A	SummitX 450-24t	SWTCH	ExtremeSwitch
extreme	N/A	SummitX 450-24x	SWTCH	ExtremeSwitch
extreme	N/A	SummitX 450a-24t	SWTCH	ExtremeSwitch
extreme	N/A	SummitX 450a-24tDC	SWTCH	ExtremeSwitch
extreme	N/A	SummitX 450a-24x	SWTCH	ExtremeSwitch
extreme	N/A	SummitX 450a-24xDC	SWTCH	ExtremeSwitch
extreme	N/A	SummitX 450a-48t	SWTCH	ExtremeSwitch
extreme	N/A	SummitX 450e-24p	SWTCH	ExtremeSwitch
extreme	N/A	SummitX 450e-48p	SWTCH	ExtremeSwitch

## HP ProCurve

### Supported OS Versions

Description	About Box Display
0.2.x	02..x
0.3.x	03..x

Description	About Box Display
0.5.x	0.5.x
0.6.x	0.6.x
07.x	07.x
08.x	08.x
09.x	09.x
1.0.x	1.0.x
10.x	10.x
11.x	11.x
12.0.x	12.0.x
13.x	13.x
14.x	14.x
15.x	15.x

## Supported Device Models

Driver	OS	Model	Common Type	Entity
procurve	HP ProCurve	A6713A Network Blade	SWTCH	HP_PROCURVE
procurve	HP ProCurve	A6716A Network Blade	SWTCH	HP_PROCURVE
procurve	HP ProCurve	A6717A Network Blade	SWTCH	HP_PROCURVE
procurve	HP ProCurve	HP J3177A AdvanceStack Switch 224T	SWTCH	HP_PROCURVE
procurve	HP ProCurve	HP J3177A AdvanceStack Switch 224VG	SWTCH	HP_PROCURVE
procurve	HP ProCurve	HP J3299A Switch 224M	SWTCH	HP_PROCURVE
procurve	HP ProCurve	HP J4110A Switch 8000M	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J3100A AdvanceStack Switch 2000	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J3100A AdvanceStack Switch 2000B	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J3175A AdvanceStack Switch 208T	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J3175A AdvanceStack Switch 208VG	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J3175A Switch 200 8/24	SWTCH	HP_PROCURVE

Driver	OS	Model	Common Type	Entity
procurve	HP ProCurve	J3245A AdvanceStack Switch 800T	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J3298A Switch 212M	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J4120A Switch 1600M	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J4121A Switch 4000M	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J4122A Switch 2400M	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J4122B Switch 2424M	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J4138A Routing Switch 9308M	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J4139A Routing Switch 9304M	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J4812A Switch 2512	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J4813A Switch 2524	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J4819A Switch 3124	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J4819A Switch 3324XL	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J4819A Switch 5308XL	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J4840A Routing Switch 6308M	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J4841A Switch 6208M	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J4860A Switch 5304XL	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J4865A Switch 4108GL	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J4874A Routing Switch 6410CL	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J4887A Switch 4104GL	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J4899A Switch 2650	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J4899B Switch 2650-CR	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J4899C Switch 2650	SWTCH	DDBASE.DEVICE
procurve	HP ProCurve	J4900A Switch 2626	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J4900B Switch 2626-CR	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J4900C Switch 2626C	SWTCH	HP_PROCURVE

Driver	OS	Model	Common Type	Entity
procurve	HP ProCurve	J4902A Switch 6108	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J4903A Switch 2824	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J4904A Switch 2848	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J4905A Switch 3400cl-24G	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J4906A Switch 3400cl-48G	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J8130A Wireless Access Point AP420WL	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J8133A Wireless Access Point AP520WL	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J8153A Access Controller 720WL	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J8154A Access Controller Server 740WL	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J8155A Integrated Access Manager 760WL	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J8164A Switch 2626-PWR	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J8165A Switch 2650-PWR	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J8433A Switch 6400cl-6XG	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J8474A Switch 6410cl-6XG	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J8680A Router 9608sl	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J8692A Switch 3500yl-24G-PWR	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J8693A Switch 3500yl-48G-PWR	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J8697A Switch 5406zl	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J8698A Switch 5412zl	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J8718A Switch 5404yl	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J8719A Switch 5408yl	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J8752A Router 7102dl	SWTCH	HP_PROCURVE

Driver	OS	Model	Common Type	Entity
procurve	HP ProCurve	J8753A Router 7203dl	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J8762A Switch 2600-8-PWR	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J8770A Switch 4204vl	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J8771A Switch 4202vl-48G	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J8772A Switch 4202vl-72	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J8773A Switch 4208vl	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J8992A Switch 6200yl-24G	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J9019A Switch 2510-24A	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J9019B Switch 2510-24	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J9020A Switch 2510-48A	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J9021A Switch 2810-24G	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J9022A Switch 2810-48G	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J9028A Switch 1800-24G	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J9029A Switch 1800-8G	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J9031A Switch 4202vl-68	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J9032A Switch 4202vl-68G	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J9038A Switch	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J9049A Switch 2900-24G	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J9050A Switch 2900-48G	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J9085A Switch 2610-24	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J9086A Switch 2610-24/12-PWR	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J9088A Switch 2610-48	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J9089A Switch 2610-48-PWR	SWTCH	DDBASE.DEVICE
procurve	HP ProCurve	J9091A Switch 8212zl	SWTCH	HP_PROCURVE

Driver	OS	Model	Common Type	Entity
procurve	HP ProCurve	J9138A Switch 2520G-8-PoE	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J9145A Switch 2910al-24G	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J9299A Switch 2520G-24-POE	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J9310A Switch 3500yl-24G-PoE	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J9311A Switch 3500yl-48G-PoE	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J9470A Switch 3500-24	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J9471A Switch 3500-24-PoE	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J9477A Switch 8206zl	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J9623A Switch E2620-24	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J9727A Switch 2520G-24-PoE	SWTCH	HP_PROCURVE
procurve	HP ProCurve	J9774A Switch 2530G-24-PoE	SWTCH	HP_PROCURVE
procurve	HP ProCurve	Proliant Series Switches	SWTCH	HP_PROCURVE

## Juniper JUNOS

### Supported OS Versions

Description	About Box Display
5.5.x	5.5R1.x/2.x/3.x/4.x
5.6.x	5.6R1.x/2.x/3.x/4.x
5.7.x	5.7R2.x
6.0.x	6.0R1.x/2.x/3.x
6.1.x	6.1R1.x/2.x/3.x/4.x
6.2.x	6.2R1.x/2.x/3.x
6.3.x	6.3R1.x/2.x/3.x/4.x
6.4.x	6.4R1.x/2.x/3.x
7.0.x	7.0R1.x/2.x

Description	About Box Display
7.1.x	7.1R1.x
7.2.x	7.2R1.x
7.3.x	7.3R1.x
7.4.x	7.4R1.x
7.5.x	7.5R1.x
7.6.x	7.6R1.x/2.x
8.0.x	8.0R1.x/2.x
8.1.x	8.1R1.x/2.x
8.2.x	8.2R1.x/2.x
8.3.x	8.3R1.x/2.x
8.4.x	8.4R1.x/2.x
8.5.x	8.5R1.x
9.0.x	9.0R1.x/2.x
9.1.x	9.1R1.x/2.x
9.2.x	9.2R1.x/2.x
9.3.x	9.3R1.x/2.x/3.x/4.x
9.4.x	9.4R1.x/2.x
9.5.x	9.5R1.x/2.x
9.6.x	9.6R1.x/2.x
10.0.x	10.0R1.x
10.1.x	10.1R1.x/2.x
10.2.x	10.2R1.x
10.3.x	10.3R1.x
10.4.x	10.4R1.x/2.x/3.x/4.x
11.1.x	11.1R1.x/2.x
11.2.x	11.2R1.x
11.3.x	11.3R1.x
11.4.x	11.4R1.x/2.x/3.x/4.x/5.x/6.x
12.1.x	12.1R1.x
12.2.x	12.2R.x
12.3.x	12.3R.x



# Supported Device Models

Driver	OS	Model	Common Type	Entity
juniper	JUNOS	EX2200 Ethernet Switch	SWRT	JuniperSwitch
juniper	JUNOS	EX3200 Ethernet Switch	SWRT	JuniperSwitch
juniper	JUNOS	EX3300 Ethernet Switch	SWRT	JuniperSwitch
juniper	JUNOS	EX4200 Ethernet Switch	SWRT	JuniperSwitch
juniper	JUNOS	EX4500 Ethernet Switch	SWRT	JuniperSwitch
juniper	JUNOS	EX6210 Ethernet Switch	SWRT	JuniperSwitch
juniper	JUNOS	EX8208 Ethernet Switch	SWRT	JuniperSwitch
juniper	JUNOS	EX8216 Ethernet Switch	SWRT	JuniperSwitch
juniper	JUNOS	FireFly_SRX	Firewall	JuniperServiceGateway
juniper	JUNOS	IP/MPLS Router Module	RTR	JuniperRouter
juniper	JUNOS	J2300 Edge Router	RTR	JuniperRouter
juniper	JUNOS	J2320 Edge Router	RTR	JuniperRouter
juniper	JUNOS	J2350 Edge Router	RTR	JuniperRouter
juniper	JUNOS	J4300 Edge Router	RTR	JuniperRouter
juniper	JUNOS	J4320 Router	RTR	JuniperRouter
juniper	JUNOS	J4350 Router	RTR	JuniperRouter
juniper	JUNOS	J6300 Edge Router	RTR	JuniperRouter
juniper	JUNOS	J6350 Router	RTR	JuniperRouter
juniper	JUNOS	LN 1000 Mobile Router	RTR	JuniperRouter
juniper	JUNOS	M10 Core/Edge Router	RTR	JuniperRouter
juniper	JUNOS	M10i Edge Router	RTR	JuniperRouter
juniper	JUNOS	M120 Router	RTR	JuniperRouter
juniper	JUNOS	M160 Core Router	RTR	JuniperRouter
juniper	JUNOS	M20 Core/Edge Router	RTR	JuniperRouter
juniper	JUNOS	M320 Core Router	RTR	JuniperRouter

Driver	OS	Model	Common Type	Entity
juniper	JUNOS	M40 Core Router	RTR	JuniperRouter
juniper	JUNOS	M40e Core/Edge Router	RTR	JuniperRouter
juniper	JUNOS	M5 Core/Edge Router	RTR	JuniperRouter
juniper	JUNOS	M7i Edge Router	RTR	JuniperRouter
juniper	JUNOS	MX240 Router	RTR	JuniperRouter
juniper	JUNOS	MX480 Router	RTR	JuniperRouter
juniper	JUNOS	MX80 Router	RTR	JuniperRouter
juniper	JUNOS	MX960 Router	RTR	JuniperRouter
juniper	JUNOS	QFX3500	SWRT	JuniperRouter
juniper	JUNOS	SRX 100 Service Gateway	SWRT	JuniperServiceGateway
juniper	JUNOS	SRX 1400 Service Gateway	SWRT	JuniperServiceGateway
juniper	JUNOS	SRX 210 Service Gateway	SWRT	JuniperServiceGateway
juniper	JUNOS	SRX 220 Service Gateway	SWRT	JuniperServiceGateway
juniper	JUNOS	SRX 240 Service Gateway	SWRT	JuniperServiceGateway
juniper	JUNOS	SRX 3400 Service Gateway	SWRT	JuniperServiceGateway
juniper	JUNOS	SRX 3600 Service Gateway	SWRT	JuniperServiceGateway
juniper	JUNOS	SRX 5600 Service Gateway	SWRT	JuniperServiceGateway
juniper	JUNOS	SRX 5800 Service Gateway	SWRT	JuniperServiceGateway
juniper	JUNOS	SRX 650 Service Gateway	SWRT	JuniperServiceGateway
juniper	JUNOS	T1600 Core Router	RTR	JuniperRouter
juniper	JUNOS	T320 Core Router	RTR	JuniperRouter
juniper	JUNOS	T640 Core Router	RTR	JuniperRouter
juniper	JUNOS	Tx Matrix	RTR	JuniperRouter
juniper	JUNOS	Tx MatrixPlus	RTR	JuniperRouter

Driver	OS	Model	Common Type	Entity
juniper	JUNOS	VMX	RTR	JuniperRouter

## WBEM Report

### Supported Device Models

Driver	OS	Model	Common Type	Entity
WBEM	N/A	RHEL	SVR	SLM-ComputerSystem
WBEM	N/A	SUSE	SVR	SLM-ComputerSystem
WBEM	N/A	VMWARE	SVR	SLM-ComputerSystem
WBEM	N/A	VMWARE HOST	SVR	SLM-ComputerSystem